Instructions Dust protection Premium Poket

Before using:

A) Square telescope track (2)

Please fit the square track on the uper door frame and leave a tolerance about 2-3 cm.

B) Telescope tracks (3)

Savare telescope track (2)

Door element (1)

Transport baa (6)

Montage:


C) Spread the door element (1) on the floor and fix the square telescope track (2) on the hook-and-loop tape.

Please holding up the door element and the square teleskope track (1+2) in the uper door frame (use only one hand) and fix it on one side by using the thumb pressure (3) like pic. A and B. Please handle with care an look out for the screw on the square teleskope track (2). It is essential that the screw is not up into the door frame!


Now fix the 2nd track.

Fit the door element (1) and put the bothe tracks as near as possible to the side frame.

<u>Caution</u>: Taking care primarily at older door frames.







Take off the tape carefully.

Release the telescope angles like pic. C).

<u>Atention:</u> Risk of injure – by loosing the

construction not carefully - it can fall down

Scope of Delivery "Premium-Set":

Item-No.

1 Pocket-door element Unit (1) L20.619

1 Square telescope track Unit (2)

spannen

