

49.27215.520 62 101 33	eingesetzt z.B. in folgenden Geräten: Electrolux-Gruppe 61115200500 19840101 Electrolux-Gruppe 61125002400 19840101 Electrolux-Gruppe 61125194400 19920101 Electrolux-Gruppe 61141600400 19800101 Electrolux-Gruppe 61141601500 19800101 Electrolux-Gruppe 61141601700 19800101 Electrolux-Gruppe 61141601900 19800101 Electrolux-Gruppe 61141600700 19800101 Electrolux-Gruppe 61141603000 19800101 Electrolux-Gruppe 61121300000 19800101 Electrolux-Gruppe 61121300100 19800101 Electrolux-Gruppe 61110598800 19830101 Electrolux-Gruppe 61121300200 19800101 Electrolux-Gruppe 61110608800 19820101 Electrolux-Gruppe 61110551000 19820101 Electrolux-Gruppe 61110618800 19830101 Electrolux-Gruppe 61120298800 19830101 Electrolux-Gruppe 61141560000 19790101 Electrolux-Gruppe 61141550000 19790101 Electrolux-Gruppe 61141601600 19800101 Electrolux-Gruppe 61141601800 19800101 Electrolux-Gruppe 61141601100 19800101 Electrolux-Gruppe 61141602600 19820101 Electrolux-Gruppe 61141602900 19800101 Electrolux-Gruppe 61115100900 19830101 Electrolux-Gruppe 61115100800 19830101 Electrolux-Gruppe 61115200400 19840101 Electrolux-Gruppe 61115000500 19840101 Electrolux-Gruppe 61115000300 19830101 Electrolux-Gruppe 61115200300 19830101 Electrolux-Gruppe 61125002600 19840101 Electrolux-Gruppe 61125002800 19850101 Electrolux-Gruppe 61125002900 19850101 Electrolux-Gruppe 61125001000 19830101 Electrolux-Gruppe 61125002300 19840101 Electrolux-Gruppe 61125002000 19830101 Electrolux-Gruppe 61115200200 19800101 Electrolux-Gruppe 61115000200 19800101 Electrolux-Gruppe 61125000600 19800101 Electrolux-Gruppe 61125001700 19820101 Electrolux-Gruppe 61125000200 19800101 Electrolux-Gruppe 61125001800 19820101 Electrolux-Gruppe 61125000100 19800101 Electrolux-Gruppe 61125000400 19800101 Electrolux-Gruppe 61125001600 19820101 Electrolux-Gruppe 61115100100 19800101
---------------------------	---

	Electrolux-Gruppe 61115101100 19820101
	Electrolux-Gruppe 61115100200 19800101
	Electrolux-Gruppe 61115101200 19820101
	Electrolux-Gruppe 61115100300 19800101
	Electrolux-Gruppe 61115101300 19820101
	Electrolux-Gruppe 61115200100 19800101
	Electrolux-Gruppe 61115201100 19820101
	Electrolux-Gruppe 61115101000 19840101
	Electrolux-Gruppe 61115100700 19830101
	Electrolux-Gruppe 61115100600 19830101
	Electrolux-Gruppe 61115100400 19840101
	Electrolux-Gruppe 61115000100 19800101
	Electrolux-Gruppe 61115001100 19820101
	Electrolux-Gruppe 61125000700 19800101
	Electrolux-Gruppe 61125001400 19820101
	Electrolux-Gruppe 61125000300 19800101
	Electrolux-Gruppe 61125001300 19820101
	Electrolux-Gruppe 61125002700 19840101
	Electrolux-Gruppe 61125001200 19830101
	Electrolux-Gruppe 61125002200 19830101
	Electrolux-Gruppe 61125000500 19800101
	Electrolux-Gruppe 61125001500 19820101
	Electrolux-Gruppe 61125001900 19830101
	Electrolux-Gruppe 61125000800 19840101
	Electrolux-Gruppe 62831004000 19800101
	Electrolux-Gruppe 62831004100 19800101
	Electrolux-Gruppe 61057502000 19770101
	Electrolux-Gruppe 61057502100 19770101
	Electrolux-Gruppe 62831001000 19790101
	Electrolux-Gruppe 62831001100 19790101
	Electrolux-Gruppe 62831002000 19790101
	Electrolux-Gruppe 62831002100 19790101
	Electrolux-Gruppe 62831003000 19790101
	Electrolux-Gruppe 62831003100 19790101
	Electrolux-Gruppe 61155710000 19760101
	Electrolux-Gruppe 61155720000 19760101
	Electrolux-Gruppe 61155800000 19760101
	Electrolux-Gruppe 61155900000 19760101
	Electrolux-Gruppe 61145900300 19830101
	Electrolux-Gruppe 61145800400 19830101
	Electrolux-Gruppe 61145900200 19820101
	Electrolux-Gruppe 61145901200 19820101
	Electrolux-Gruppe 61145900100 19810101
	Electrolux-Gruppe 61145800100 19810101
	Electrolux-Gruppe 61145800300 19810101
	Electrolux-Gruppe 61145801200 19820101
	Electrolux-Gruppe 61145800200 19810101
	Electrolux-Gruppe 61145801300 19820101
	Electrolux-Gruppe 61145800500 19830101

	Electrolux-Gruppe 6115110000 19830101 Electrolux-Gruppe 6115210000 19830101 Electrolux-Gruppe 61125020000 19830101 Küppersbusch EEHS 605 HW
--	--