

<b>DE</b> Montageanleitung ViCare Heizkörper-Thermostat	<b>LT</b> Montažo instrukcija ViCare radiatoriaus termostatas
<b>GB</b> Installation instructions ViCare Radiator Thermostat Valve	<b>LV</b> Montāžas instrukcija ViCare sildīkļa termostats
<b>FR</b> Notice de montage Thermostat de radiateur ViCare	<b>NL</b> Montagevoorschriften ViCare radiatorthermostaat
<b>BG</b> Употреба за монтаж ViCare термостат за радиатори	<b>PL</b> Instrukcja montażu Termostatu grzejnikowego ViCare
<b>CN</b> 安装指南 ViCare散热器温控阀	<b>PT</b> Instruções de montagem Termostato dos radiadores ViCare
<b>CZ</b> Návod k montáži Termostát topného tělesa ViCare	<b>RO</b> Instrucțiuni de montaj pentru Termostatul ViCare pentru radiatoare
<b>DK</b> Montagevejledning Termostat ViCare	<b>RS</b> Uputstvo za montažu ViCare termostata radijatora
<b>EE</b> Paigaldusjuhend ViCare küttekeha termostaadi	<b>RU</b> Адаптер фланца терморегулирующего вентиля радиаторов ViCare
<b>ES</b> Instrucciones de montaje ViCare termostato del radiador	<b>SE</b> Montageinstruktion ViCare radiatortermostat
<b>FI</b> Asennusohje ViCare-lämpöpatteritermostaatti	<b>SI</b> Navodilo za montažo ViCare radiatorski termostat
<b>HR</b> Uputa za montažu ViCare termostata za radijatore	<b>SK</b> Montážny návod Termostát vykurovacieho telesa ViCare
<b>HU</b> Szerelési utasítás ViCare fűtőtest-termostát	<b>TR</b> Montaj Kılavuzu ViCare Isitici Termostatı
<b>IT</b> Istruzioni di montaggio Termostato per radiatori ViCare	<b>UA</b> Інструкція з монтажу термостата радіатора ViCare




<https://viessmann.zendesk.com/hc/>



[www.vicare.info](http://www.vicare.info)

Viessmann Werke GmbH & Co. KG  
35108 Allendorf  
Telefon: +49 6452 70-0  
Telefax: +49 6452 70-2780  
[www.viessmann.com](http://www.viessmann.com)



**1**

**2**

**3**

2 x AA/LR6 1,5 V

**4**

**5**

**6**

**7**

**8**

**9**

**10**

**11**

7637434

FCC ID: 2AIZ9-TR0618  
IC: 21680-TR0618

f: 2405,0 - 2480,0 MHz  
P<sub>max</sub>: 0,1 W (e.i.r.p.)

