


R284Y021

047U57348 Dicembre 2016 - December 2016

ISTRUZIONI KIT DI BY-PASS DIFFERENZIALE
DIFFERENTIAL BY-PASS KIT INSTRUCTION

 **GIACOMINI**
WATER E-MOTION



IT

Per installare il kit R284Y021 sui gruppi R586R procedere come segue:

- Chiudere le valvole a sfera a monte e a valle del gruppo R586R.
- Rimuovere i tappi dalle valvole di intercettazione premontate sul gruppo R586R.
- Installare il kit R284Y021 inserendo prima le 2 guarnizioni e successivamente avvitando le calotte sugli attacchi filettati delle valvole di intercettazione. ⚠ Prestare attenzione al senso di installazione del kit: l'estremità dove è presente la valvola di ritegno deve essere installata sullo stacco di ritorno del gruppo R586R.

EN

To install the R284Y021 kit on R586R units, proceed as follow:

- Close the interception valves downstream and upstream the R586R unit.
- Remove the caps preassembled on the R586R unit.
- Install the R284Y021 kit by inserting before the 2 gaskets and then screwing nuts onto the threaded connections of the interception valves. ⚠ Pay attention to installation direction of the kit: the end where there is the check valve must be installed on the R586R unit return output.

